



Contents:





(1) Lock Cylinder



(1) Nut



(1) Lock Tang






(1) Phillips (1) Key Head Screw

Tools Required:



Phillips Head Screwdriver (not included)



Adjustable Wrench or Pliers (not included)

- Remove plug from drawer by squeezing two clips on the plug inside the drawer face.
- Replace plug with Lock Cylinder making sure Lock Cylinder face is oriented as shown.
- Securely tighten Nut onto Lock Cylinder from inside the drawer with an adjustable wrench or pliers.
- Place Lock Tang onto Lock
 Cylinder with the bend in the
 Tang going towards the front of
 the drawer as shown.
- Using screwdriver tighten phillips head screw into the end of the Lock Cylinder to secure the Lock Tang.

6 Check to make sure key properly operates lock.

